

1) Downloading and Installing the WalkingHotSpot Application

WalkingHotSpot® (WHS) is delivered as a self extracting file that can be downloaded to your smartphone from the internet. Just follow the simple prompts on your phone to install. Windows Mobile and Symbian S60 operating systems are supported. It is recommended that you have an unlimited data plan with your network carrier operator.

2) Starting WalkingHotSpot

To run WalkingHotSpot, locate and select the WHS icon (pictured above):

Symbian S60: in the folder where installed applications are stored (“Installations” or “Applications”)

Windows Mobile: in the Programs folder

WalkingHotSpot launches in the idle state as denoted by the red “OFF” on the WHS status screen. To begin using the WHS device (phone) as an access point or WalkingHotSpot, select “Start” from the WHS status screen. WalkingHotSpot is active and ready for connections when the status changes to a green “ON”. Until you purchase a service plan the registration screen will pop up. If you have purchased WalkingHotSpot and have a 12 digit code, enter it in the boxes displayed on the phone and select **Register**; if not, select **Skip**.

3) Configuring WalkingHotSpot

There are a number of settings defined in the user’s guide but the only required setting is the operator access point. To do that, execute the following button sequence on your smartphone:

[Options] ▶ [Settings] ▶ [Network] ▶ [Operator access point]

This will display a screen that lists the available access points for connectivity. This is the high speed connection from the mobile network operator that will be used for internet connectivity (backhaul). Please ensure that the proper selection is made. If there are any questions on which access point to use, contact your carrier to verify which network access point should be used for internet connectivity.

4) Connecting Clients to WalkingHotSpot

WalkingHotSpot is active and ready for connections when the status shows a green “ON” (section 2 above). Five WHS clients can simultaneously connect to the Internet with WalkingHotSpot. Black circles represent the number of available connections (IP addresses) while green circles indicate the number of active connections. Connecting a laptop or other Wi-Fi device to your WalkingHotSpot is easy! Simply perform the button press sequence (on your PC or iPod touch) as defined below. These instructions are for standard configurations. If your device is not shown or you are experiencing trouble please refer to your user guide for specific instructions.

Windows XP laptop - [Start] ▶ [Connect To] ▶ [Wireless Network Connection] ▶ select your WalkingHotSpot from the list ▶ [CONNECT] ▶ [Connect Anyway] ▶ answer YES on your phone’s screen

Windows Vista laptop - [Start] ▶ [Network] ▶ [Network & Sharing Center] ▶ [Connect to a network] ▶ select your WalkingHotSpot from the list ▶ [CONNECT] ▶ [Connect Anyway] ▶ answer YES on your phone’s screen

Mac - [System Preferences] ▶ [Network] from Internet & Networking section ▶ [Air Port] make sure Air Port is ON ▶ click the arrow beside the [Network Name] box ▶ select your WalkingHotSpot from the list and answer YES on your phone’s screen

iPod touch - [Settings] ▶ [WiFi] make sure Wi-Fi is ON ▶ [Choose a Network] select your WalkingHotSpot from the list and answer YES on your phone’s screen

5) Exiting the Application

From the main WalkingHotSpot screen, select “Options” and then “Exit”. This will terminate the WalkingHotSpot and stop any active connections.